

# MILLER RELIEF STEP™ SAFETY DEVICE Model 9099



## Prevent Suspension Trauma

Easily attaches to  
all full-body harness  
brands or models.

- OSHA states that suspension trauma can occur within minutes after a fall, while waiting for rescue.
- Average fall rescue time is 15 minutes.
- Relief Step provides support and helps blood circulation until rescue.
- Small and lightweight; Relief Step attaches to any brand full-body harness.

Honeywell Safety Products  
800-873-5242

## INSTALLATION INSTRUCTIONS



1. Mount to upper rear web strap by "choking" through loop (Be sure loop is past metal adjustments.)



2. Attach "pull tab" button loop to the front leg strap above buckle.

## ACTIVATION STEPS



**STEP 1: Unsnap and pull orange tab to deploy.**



**STEP 2: Insert opposite foot into loop.**



**STEP 3: Adjust length and step up to relieve pressure.**



**Use two Relief Steps for optimum support.**

[www.millerfallprotection.com](http://www.millerfallprotection.com)



by Honeywell



**Cental Telefónica**  
01 624 3435

[ventas@imrecard.com](mailto:ventas@imrecard.com)

**Lima:**

Huayucari 172 Coop. 27 de Abril - Ate.

**Arequipa:**

Las Orquídeas 204-206 Urb. Primavera - Umacollo.

**La libertad**

Los Jazmines Mz 9 Lt.11 Dpto 101 Urb. Jardines del Golf  
Victor Larco Herrera - Trujillo